

## FCC COMPLIANCE

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## TROUBLESHOOTING AND TIPS

1. If the voice becomes weak or low, replace the batteries with fresh AAA Alkaline batteries.
2. When not playing with your Pet, be sure to turn it "OFF" to save battery power.
3. When not in use for an extended time, remove batteries to prevent possible leakage and damage to the unit.
4. If the pet is exposed to an electrostatic environment, (static electricity) it may malfunction. If this happens, replace the batteries to reset the pet.



'Let's care for the environment!  
The wheelie bin symbol indicates that the product must not be disposed of with other household waste. Please use designated collection points or recycling facilities when disposing of the item.

### DISPOSAL OF BATTERIES

Do not treat old batteries as household waste. Take them to an applicable collection point for battery recycling.

Please keep this manual as it contains important information.



0808-0-E

www.rescue-pets.com  
RESCUE PETS™ used under exclusive license from AAA, JUST BORN, WAKE ME UP™, MYEPETS.COM™, DIGI-TAILS™ and all other materials, including character art, the pets themselves and all related artwork, logos, designs and packaging are property of MGA Entertainment.  
16300 Roscoe Blvd.  
Van Nuys, CA 91406 USA  
(800) 222-4685  
Printed in China

The preferred method of contact for Customer Service is through our e-mail contact form at [www.mgae.com](http://www.mgae.com)



Ages 3+

Item No.: 356608


ADULT BATTERY INSTALLATION REQUIRED



This cute little stray needs you to save the day! This adorable little Rescue Pet isn't feeling too well and he needs your help to get better! Use the stethoscope to check him out and put a cast on his paw to make him feel better!!

## CONTENTS

- |                                     |                           |
|-------------------------------------|---------------------------|
| a. 1 Rescue Pet with collar and tag | e. 1 Adoption Certificate |
| b. 1 Stethoscope                    | f. 1 Heart-Shaped Sticker |
| c. 1 Hypodermic                     | g. 1 My e-pets Code Card  |
| d. 1 Cast                           |                           |




Illustrations may vary from actual contents.

## BEFORE YOU BEGIN

The batteries included in your Rescue Pets™ are for in-store demonstration. It is recommended that, prior to playing, fresh alkaline batteries (not included) be installed for best performance. An adult must install batteries. Here's how:

### TO INSTALL BATTERIES:

1. Pull apart the opening located on the pet's tummy.
2. Using a Phillips screwdriver (not included) remove the screw and battery compartment cover.
3. Install three (3) AAA alkaline batteries (not included) making sure the (+) and (-) ends face the proper direction as indicated inside the battery compartment. (Fig. 1)
4. Replace the compartment cover and tighten the screw.
5. Turn the "TRY ME/ON/OFF" switch on the side of the battery compartment to "ON".
6. Close the opening on the pet's tummy.



## ADOPTING YOUR RESCUE PETS™

1. Officially adopt your Rescue Pets™ by filling in the adoption certificate information. Go to:
  - a. [www.rescue-pets.com](http://www.rescue-pets.com)
  - b. Click on "Adoption Center."
  - c. Click on the picture of your pet.
  - d. Fill in the Adoption Certificate.
  - e. Click on "Create Certificate."
  - f. Click on the size of Certificate from "Print options" you wish to print.
  - g. Click "Print" for printing certificate, then click "Done."
  - h. You have officially adopted your very own Rescue Pet!

There are many more fun things to do on the website. Check it out and keep coming back.

2. Write your Rescue Pet's name on the heart-shaped sticker and apply the sticker to the tag on its collar.

## REGISTERING YOUR PET

To create your pet and its virtual room, please follow these instructions:


### GETTING CONNECTED (FIRST TIME):

1. With an adult's permission, get connected to the Internet.
2. Go to [www.mypets.com](http://www.mypets.com)
3. At the Welcome Screen, click on "Fetch" underneath "New to MyePets".
4. Follow the prompts to register you, your MyePet and create a new account.
5. Write down your User Name and Password, and keep them in a safe place.


**NOTE:** Don't forget, you will need your secret code. It's on the code card attached to your pet. Once the code is entered, use your User Name and password to log on.

**NOTE:** If you have any privacy questions, please refer to MGA's Privacy policy at <http://www.mgae.com/privacy.asp>


## QUICK START




1. Pet the hair on his head firmly and he will happily greet you. (Fig. 2)



2. Press the Stethoscope under your pet's chin. You'll hear his healthy heart beating. (Fig. 3)



3. To give him a shot, press the end of the Hypodermic on the spot on his hindquarters. He'll bark when you hit the right spot. (Fig. 4)



4. If you squeeze the Pet's left front paw, it will glow and he will whimper (Fig 5a). Place the Cast over his paw (Fig. 5b) and he will feel better.

**NOTE:** Your pet will **ONLY** stop whimpering if you place the cast over his paw or squeeze both sides of his paw at the same time.

## SAFETY INSTRUCTIONS

### ⚠ CAUTION:

1. DO NOT sit or stand on any part of the Pet.
2. DO NOT spill food and/or beverages on the Pet.
3. DO NOT throw or kick the Pet.
4. DO NOT expose your Pet to moisture of any kind.

## CLEANING INSTRUCTIONS

To clean your Pet, brush it with a cloth or soft brush to loosen any dirt. Then use a slightly damp cloth to remove any stains.

- DO NOT put your Pet into the washing machine.
- DO NOT use detergent or stain removers on the plush covering of the Pet.
- DO NOT submerge your Pet in water.
- DO NOT expose your Pet to moisture of any kind.
- DO NOT put the Pet into a dryer or subject it to heat of any kind.
- Wipe dirt off immediately to prevent stains.
- If the Pet gets wet, remove the batteries immediately and let the Pet air dry.
- Once the Pet is dry, replace the batteries.

## SAFE BATTERY USAGE

- Use alkaline batteries for best performance and longer life.
- Use only the type battery recommended for the unit.
- Batteries should be replaced only by an adult.
- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not short-circuit batteries.
- When not used for an extended time, remove batteries to prevent possible leakage and damage to the unit.
- Do not mix rechargeable and non-rechargeable batteries.
- Rechargeable batteries are to be removed from the toy before charging.
- Rechargeable batteries are to be recharged only under adult supervision.
- Do not recharge non-rechargeable batteries.
- Exhausted batteries are to be removed from the toy.
- Do not dispose of batteries in fire as they may leak or explode.

**NOTE:** The voltage of a fully-charged, rechargeable battery is often lower than that of a fresh alkaline battery. Therefore, it is recommended that alkaline batteries be used instead of rechargeable batteries for best performance and for longest play time.