

## TROUBLESHOOTING

1. My computer will not recognize the webcam.	Please check the following things: <ul style="list-style-type: none"> <li>• Make sure that your USB Webcam is plugged into an active USB Port.</li> <li>• If you are not sure, try unplugging it and plugging it into another port.</li> <li>• Download and install the driver software from <a href="http://www.be-bratz.com/drivers/">http://www.be-bratz.com/drivers/</a>.</li> </ul>
2. My Webcam image is blurry.	Turn the Focus Knob on the Webcam lens left and right until the image is clear.

## SPECIFICATIONS

- CMOS sensor
- Video capture: up to 352 x 288 pixels
- Still image capture: up to 640 x 480 pixels
- USB 2.0 compatible
- Manual focus lens
- Frame rate: up to 30 fps

## FCC STATEMENT

### FCC Compliance

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



'Let's care for the environment!'

The wheelie bin symbol indicates that the product must not be disposed of with other household waste. Please use designated collection points or recycling facilities when disposing of the item

Please keep this manual as it contains important information.

Windows® is a registered trademark of Microsoft Corporation in the United States and other countries.



0507-0-E/INT

www.bratz.com  
 TM & © MGA Entertainment, Inc.  
 BRATZ™, BRATZ PETZ™, LIL' BRATZ™,  
 BRATZ BABYZ™, BRATZ KIDZ™ and all related  
 logos, names, characters, distinctive likenesses  
 and slogans, as well as the packaging and  
 images appearing thereon, are the exclusive  
 property of MGA.  
 16300 Roscoe Blvd.,  
 Van Nuys, CA 91406 USA  
 (800) 222-4685  
 Printed in China

The preferred method of contact for  
 Customer Service is through our e-mail  
 contact form at [www.mgae.com](http://www.mgae.com)



Item no.: 366560

ADULT SUPERVISION REQUIRED

## INTRODUCTION

Personalize your computing station with hot new Bratz™ designed computer accessories.

## CONTENTS

- 1 Be-Bratz.com™ USB Webcam

## BEFORE YOU BEGIN

### Minimum (Recommended) System Requirements:


- CPU 800MHz or higher utilizing Windows® ME, 2000, XP or Vista as the operating system.
- A USB port
- A monitor with 800 x 600 pixels of resolution
- 512 MB RAM
- 100 MB free disk space
- Windows® compatible Sound Card with microphone and speakers

NOTE: PC's running Windows® 2000, ME, XP or Vista will need to download and install driver software. Please refer to the "Installing Driver Software" section below.

### INSTALLING DRIVER SOFTWARE:

If your PC is unable to detect and install the Webcam automatically, then you will need to download and install driver software. Here's how:

1. With an adult's permission, get connected to the internet.
2. Go to <http://www.be-bratz.com/drivers/> and click on the Download button.
3. Once the software is downloaded to your hard drive, double-click on it to start installation.
4. Follow the steps in the installation wizard.
5. Once the software is installed, you should be able to use your Webcam!



### CONNECTING THE USB WEBCAM:

1. Make sure that the driver is installed on your computer.
2. Plug the USB Port on your Webcam into a free USB port on your PC. (Fig. 1).
3. The PC will automatically detect the Webcam.
4. Use your new Webcam with the other Be-Bratz.com™ accessories. (not included).

NOTE: If the camera does not work or the PC cannot detect it, please refer to the Troubleshooting section at the end of this manual.

## QUICK START

### USING YOUR WEBCAM:

Your Be-Bratz.com™ Webcam can be used for many different activities including:

- Live video images with videoconferencing software (not included).
- Take still pictures and email them to your friends with photo capture software (not included).
- Video Instant Messaging with popular Instant Message software packages (not included).
- Monitor your computer remotely with monitoring software (not included).

## SAFETY INSTRUCTIONS

- Adult supervision is required when children are using the Webcam.
- Never unplug your Webcam from the USB port when the computer is turned ON.
- Avoid using the Webcam under direct sunlight, or in extremely hot, cold or dusty environments.