

FCC Compliance

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Let's care for the environment!
The wheelie bin symbol indicates that the product must not be disposed of with other household waste. Please use designated collection points or recycling facilities when disposing of the item.

DISPOSAL OF BATTERIES: Do not treat old batteries as household waste. Take them to a designated recycling facility.



Ages 3+

Item no.: 377825

ADULT BATTERY INSTALLATION REQUIRED


INTRODUCTION

This cute little stray loves to swim all day! As soon as you place this perky pup in the water, he begins to do a doggy paddle! Place him on land, and he walks to you with his head held high! He also comes with a towel and stylin' dog-goggles!

CONTENTS

Welcome your Rescue Pet to your home by making sure the package contains:

- 1 Rescue Pets™ Swim to Me Puppy™
- 1 Adoption Certificate
- 1 Towel
- 1 Pair of Goggles



Illustrations may vary from contents.


BATTERY INSTALLATION

Before taking your new Puppy for a walk (or swim), have an adult install fresh alkaline batteries by following these steps:

1. Using a Phillips screwdriver (not included), remove the screws and battery compartment cover from the Puppy's tummy. (Fig. 1)
2. Insert three (3) 1.5V AAA batteries (not included) with the positive (+) and negative (-) ends facing the proper direction as indicated inside the battery compartment.
3. Replace the battery compartment cover and tighten the screw securely to ensure a water tight seal.
4. Your Puppy is now ready to go swimming!

Important Notes:

- Dry the Puppy thoroughly before opening the battery compartment.
- If moisture is present in the battery compartment, dry it with a towel.



Please keep this manual as it contains important information.



0308-0-E/INT

www.rescue-pets.com
RESCUE PETS™ used under exclusive license from AAA. JUST BORN, WAKE ME UP™, MYEPETS.COM™, DIGI-TAILS™ and all other materials, including character art, the pets themselves and all related artwork, logos, designs and packaging are property of MGA Entertainment, 16300 Roscoe Blvd, Van Nuys, CA 91406 USA (800) 222-4685 Printed in China

The preferred method of contact for Customer Service is through our e-mail contact form at www.mgae.com



QUICK START

ON LAND

1. Press the Walk Switch on the Puppy's heart-shaped collar tag until his legs begin to move (Fig. 2).
2. Place the Puppy on a flat, level surface and he will begin to walk. (Fig. 3).
3. To turn off the Puppy, firmly press the Walk Switch for two seconds. When you release the Switch, he will stop walking.

IN WATER

⚠ CAUTION: Do not allow children to play in water without ADULT SUPERVISION.

1. Place the Dog Goggles over the Puppy's head.
2. Set the Puppy in a bathtub, swimming pool or other large container of clean, clear water.
3. As soon as the Puppy's sensors touch the water, he begins to kick his legs. (Fig. 4 & 5)
4. Let go of the Puppy and he will swim straight ahead.
5. Bring the Puppy out of the water and his legs will stop moving as soon as his sensors are dry.
6. For best results, hold the Puppy's body under water until all of the air bubbles disappear from the hole in the Puppy's back. This will help keep the Puppy balanced while swimming.

NOTE: If you remove the Puppy from the water and he does not stop swimming, firmly press and hold the Walk Switch for two seconds to turn the Puppy off.

Important Note: NEVER place the Puppy in any liquids other than clean, clear water as this can cause irreparable damage!

Important Notes:

- Do not keep your Puppy in bath, salt or chlorinated pool water as discoloration or bleaching may occur.
- Do not apply any make-up or skin care products (like sunscreen) to your Puppy.
- When bathing, use only cold or lukewarm water and mild soap products for children.

NOTE: The Swim to Me Puppy must be cleaned and dried after bathing. Please refer to the CLEANING INSTRUCTIONS section at the end of this manual.




⚠ CAUTION: Do not use the Swim to Me Puppy as a floatation device!

ADOPTING YOUR RESCUE PET

Officially adopt your Rescue Pets™ Swim to Me Puppy™ by filling in the adoption certificate information. To do so, go to:

- a. www.rescue-pets.com
- b. Click on "Adoption Center."
- c. Click on the picture of your pet.
- d. Fill in the Adoption Certificate.
- e. Click on "Create Certificate."
- f. Click on the size of Certificate you wish to print from "Print Options".
- g. Click "Print", and then click "Done."
- h. You have officially adopted your very own Rescue Pet.

There are many more fun things to do on the Rescue Pets™ website. Check it out and keep coming back.



TROUBLESHOOTING

If the motion of your Swim to Me Puppy becomes slow or fails to work, replace the batteries with fresh AAA Alkaline batteries.

CLEANING INSTRUCTIONS

To clean your Puppy, use a slightly damp cloth to remove any stains.

- DO NOT put your Puppy into the washing machine.
- DO NOT use detergent or stain removers on the Puppy.
- DO NOT submerge your Puppy completely in water.
- Wipe dirt off immediately to prevent stains.
- If water gets into the battery compartment, remove the batteries immediately and let the open compartment air dry.
- DO NOT put the Puppy into a dryer or subject it to heat of any kind.
- After play, drain excess water from the hole on the Puppy's back and head. Dry the Puppy thoroughly and bring indoors. Prolonged exposure to sunlight will cause damage to the Puppy.

SAFETY INSTRUCTIONS

⚠ CAUTION:

- Adult supervision REQUIRED when children are playing around water.
- Please follow all instructions in this manual when playing with the Puppy in water.
- Be sure to clean and dry the Puppy after going in the water, otherwise it might develop mold or mildew.
- If the Puppy will not be played with for extended period of time, remove the batteries to prevent possible corrosion and damage to the toy.
- DO NOT allow children to play in water that is near an electrical source or apparatus in order to avoid electric shock and/or electrocution.
- DO NOT leave the Puppy near an electrical source or apparatus when wet.
- DO NOT place the Puppy in extremely hot or extremely cold water.
- Not recommended for outdoor use.
- DO NOT sit or stand on any part of the Puppy.
- DO NOT throw or kick the Puppy.
- Operate the toy in water only when fully assembled in accordance with the instructions.

SAFE BATTERY USAGE

- Use alkaline batteries for best performance and longer life
- Use only the type battery recommended for the unit.
- Batteries should be replaced only by an adult.
- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not short-circuit batteries.
- When not used for an extended time, remove batteries to prevent possible leakage and damage to the unit.
- Do not mix rechargeable and non-rechargeable batteries.
- Rechargeable batteries are to be removed from the toy before charging.
- Rechargeable batteries are to be recharged only under adult supervision.
- Do not recharge non-rechargeable batteries.
- Exhausted batteries are to be removed from the toy.
- Do not dispose of batteries in fire as they may leak or explode.

NOTE: The voltage of a fully-charged, rechargeable battery is often lower than that of a fresh alkaline battery. Therefore, it is recommended that alkaline batteries be used instead of rechargeable batteries for best performance and for longest play time.