

FCC COMPLIANCE

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT

• EMISSIONS OR INTERFERENCE OF SURROUNDING ELECTRONIC EQUIPMENT MAY AFFECT OPERATING PERFORMANCE.

CAUTION

- DO NOT operate this vehicle during thunderstorms.
- DO NOT expose the vehicle or remote control to water or moisture of any kind as it may cause irreparable damage to the unit.
- Keep hair, loose clothing and other items away from rotating wheels of the unit.

HELPFUL HINTS

- Since your vehicle is controlled by radio frequency, it may interfere with other radio controlled devices. If this occurs, move the vehicle to another location away from the interference.
- The vehicle must remain in remote control range to operate correctly. The range depends on the surrounding area and on the strength of the battery. Obstructions such as buildings, fences, etc., between the remote control transmitter and the vehicle may reduce the range.
- If the vehicle begins to run slowly, replace the batteries with fresh alkaline batteries.
- Remember, trucks of the same color operate under the same radio frequency and if raced together will not perform as designed.



'Let's care for the environment!
The wheeler bin symbol indicates that the product must not be disposed of with other household waste. Please use designated collection points or recycling facilities when disposing of the item.

DISPOSAL OF BATTERIES:

Do not treat old batteries as household waste. Take them to a designated recycling facility.

Please keep this manual as it contains important information.



© MGA Entertainment, Inc.
16300 Roscoe Blvd.
Van Nuys, CA 91406 USA
(800) 222-4685
Printed in China



Spider-Man, the Character: TM & © 2007 Marvel Characters, Inc.
Spider-Man 3, the Movie: © 2007 Columbia Pictures Industries, Inc.
All Rights Reserved.

This MONSTER TRUCK R/C is manufactured and distributed by
MGA Entertainment, Inc. under license from Spider-Man Merchandising L.P.

The preferred method of contact for
Customer Service is through our e-mail
contact form at www.mgae.com



0507-2

SPIDER-MAN 3

SPIDER-MAN™ MONSTER TRUCK R/C RADIO CONTROL

Item no.: 351832 / 351832XX


Ages 6+

INTRODUCTION


It's time to hit the road in monster crushing style! These huge radio-controlled Spider-Man 3™ Monster Trucks are strong and unstoppable just like Spider-Man™ himself!

CONTENTS

- 1 Spider-Man 3™ Monster Truck
- 1 Remote Control
- 6 - (1.5V AA) Batteries
- 1 - (9 V) Battery



Spider-Man 3™ Monster Truck



Remote Control

Illustrations may vary from actual contents.

BEFORE YOU BEGIN

Before setting your sights on your next crushing victim, an adult must install batteries in your mean machine. Here's how:

REMOTE CONTROL

1. Using a Phillips screwdriver (not included) remove the screw and battery compartment cover from the back of the remote control. (See Fig. 1)
2. Install one (1) 9-Volt alkaline battery (included) making sure the (+) and (-) ends face the proper direction as indicated on the battery connector.
3. Replace the compartment cover and tighten the screw.

VEHICLE

1. Using a Phillips screwdriver (not included) remove the screw and battery compartment cover from the bottom of the vehicle. (See Fig. 2)
2. Install six (6) 1.5V AA alkaline batteries (included) making sure the (+) and (-) ends face the proper direction as indicated inside the battery compartment.
3. Replace the compartment cover and tighten the screw.

Fig. 1





Fig. 2



VEHICLE TUNE-UP: STEERING ADJUSTMENT

1. Adjust your vehicle's steering by rotating the Steering Knob bit by bit. (See Fig. 2)
2. After each adjustment, place your vehicle on the ground and take it for a spin!
3. Repeat these steps until you get the best steering action for your vehicle.





QUICK START

Get ready to roll like thunder! Here's how to get your Spider-man 3™ Monster Truck moving:

1. Turn the ON/OFF switch on the bottom of the Vehicle to ON. (See Fig. 2)
2. Turn the ON/OFF switch on the Remote Control to ON. (See Fig. 1)
3. Place the Vehicle on a flat, level surface away from traffic of any kind.
4. Operate the vehicle with the remote control by using the rocker switches.
 - a. Left rocker switch
 - Press up to move vehicle forward. (See Fig. 3)
 - Press down to move vehicle backward. (See Fig. 4)
 - b. Right rocker switch
 - Press left to move vehicle to the left. (See Fig. 5)
 - Press right to move vehicle to the right. (See Fig. 6)

Use combinations of the two rocker switches for tight turns, quick maneuvers and fast acceleration. Invite your friends to bring their very own Spider-Man™ Monster Trucks for exciting crushing and racing action!

NOTE: When racing two Spider-Man™ RC trucks, they must be of different radio frequencies (e.g. 40MHz against 27MHz) or they may not perform as designed.



NOTE: When finished playing, be sure to turn the ON/OFF switch to OFF for both the R/C Vehicle and the remote control unit. This will prevent the batteries from draining when the R/C Monster Truck is not in use. If the R/C Monster Truck is not to be used for long periods of time, be sure to remove the batteries to prevent corrosion.

SAFE BATTERY USAGE

- Use alkaline batteries for best performance and longer life.
- Use only the type battery recommended for the unit.
- Batteries should be replaced only by an adult.
- Insert batteries with the correct polarity (+ and -).
- Do not mix different types of batteries or old and new batteries.
- Do not short-circuit batteries.
- When not used for an extended time, remove batteries to prevent possible leakage and damage to the unit.
- Do not mix rechargeable and non-rechargeable batteries.
- Rechargeable batteries are to be removed from the toy before charging.
- Rechargeable batteries are to be recharged only under adult supervision.
- Do not recharge non-rechargeable batteries.
- Exhausted batteries are to be removed from the toy.
- Do not dispose of batteries in fire as they may leak or explode.

NOTE: The voltage of a fully-charged, rechargeable battery is often lower than that of a fresh alkaline battery. Therefore, it is recommended that alkaline batteries be used instead of rechargeable batteries for best performance and for longest play time.